

SIZE CHARTS

APPAREL

Men's (metric)

Size (cm)	Chest	Waist	Hip	Inseam		
				Regular	Short	Long
S	88-96	73-81	88-96	82-5	77-5	87-5
M	96-104	81-89	96-104	83	78	88
L	104-112	89-97	104-112	83-5	78-5	88-5
XL	112-124	97-109	112-120	84	79	89
XXL	124-136	109-121	120-128	84-5	79-5	89-5
XXXL	136-148	121-133	128-136	85	80	90

Women's (metric)

Size (cm)	Bust	Waist	Hip	Inseam		
				Regular	Short	Long
S	83-90	67-74	91-98	79-5	74-5	84-5
M	90-97	74-81	98-105	80	75	85
L	97-104	81-88	105-112	80	75	85
XL	104-114	88-98	112-120	80.5	75.5	85.5

Kids' (metric)

Size (cm)	Chest	Waist	Hip	EMEA Height	
				Regular	Long
XS	64.5-66	59.5-61.5	68.5-71	122-128	
S	66-69	61.5-65	71-74.5	128-137	
M	69-75	65-69	74.5-79.5	137-147	
L	75-81.5	69-72.5	79.5-84.5	147-158	
XL	81.5-88.5	72.5-75.5	84.5-89.5	158-170	

Little Kids' (metric)

Size (cm)	Numeric Size	Chest	Waist	Hip	Height	Age
S	5	56-59	56-58	59-61	104-110	4-5
M	6	59-61	58-59	61-63	110-116	5-6
L	6X/7	61-63	59-60	63-66	116-122	6-7
XL	7X	63-66	60-61	66-70	122-128	7-8

SOCKS



Men's & Women's (unisex)

Size	Europe Shoe	UK Shoe	Men's US Shoe	Women's US Shoe	cm
XS	30-34	12-2	13C-3Y		19-21
S	34-38	2-5	3Y-5Y	4-6	21-24
M	38-42	5.5-7.5	6-8	6-10	24-27
L	42-46	8-11	8-12	10-13	27-30
XL	46-50	11-14.5	12-15		30-33

BALLS

Junior - Youth - Adult

Size (cm)	3	4	5	Age
Junior	58.5-61			8 and younger
Youth		63.5-66		8-12
Adult			68-70	13+



NIKE FIT SYSTEM



DRI-FIT: Pulls away sweat to help keep you dry and comfortable.
DRI-FIT SPHERE: 3-D construction helps keep you dry and reduces cling from sweat.



STORM-FIT 1: Helps keep you dry and comfortable in moderate weather conditions.
5,10 & 20: Helps keep you comfortable and dry in rain, sleet and snow.
 The seam-sealed, breathable fabric completely blocks wind and rain penetration at:
STORM-FIT 5: up to 5,000 mm of water pressure
STORM-FIT 10: up to 10,000 mm of water pressure
STORM-FIT 20: up to 20,000 mm of water pressure

WASH INSTRUCTIONS

CARE INSTRUCTIONS FOR NIKE TEAM SPORTS APPAREL PRODUCT

Care for jerseys promptly. The sooner you pre-treat and launder the stained clothes, the better your results will be. Don't allow mud or stains to set. Do not leave wet or dirty jerseys in football or gym bags, where smells and permanent stains can develop.

If a stain is not removed in washing:

1. Do not dry it. Dryer heat will set the stain.
2. Soak the stain in a pre-wash. In the case of severe staining it may be necessary to apply a stain remover directly to the affected area. Then launder again.
3. Do not dry a garment until the stain is removed because dryer heat will set the stain.

Once stain is removed launder as per usual custom.

CARE DEFINITIONS

Pre-treat heavily soiled spots. Apply undiluted laundry detergent with a bleach alternative. Pre-soak heavy stains. Soak stained items in a plastic bucket or laundry tub with the warmest water safe for the fabric and a good laundry detergent for one to three hours. Sensitive stains should be rinsed in cold water, and then washed with a non-chlorine bleach product.

Pre-wash: Used for heavily soiled garments. Run through the pre-wash cycle with the recommended amount of detergent.

When wash cycle is complete, drain the pre-wash solution and launder in the hottest water recommended by the manufacturer.

Please check the washing instructions on the garment.

DISCLAIMER

This Nike Team Football catalogue has been created to offer a comprehensive view of products available for sale to teams. Whilst the information provided in this catalogue has been gathered and assembled with every effort made to ensure the accuracy of the content, Nike does not make any warranty in respect of this information. Nike reserves the right to change items in the product line or their individual specification at any time.